

## SUPPORTED DEVICE/BROWSERS

### IOS SUPPORTED DEVICES

#### iOS Device / OS Version

- iPhone 4S - OS:8.4
- iPhone 5S - OS:8.4
- iPhone 6 Plus - OS:8.4
- \*iPad Mini - OS: 8.4
- iPad Mini 2 - OS: 8.4
- iPad 2 - OS: 8.4

### ANDROID SUPPORTED DEVICES

#### Android Device / OS Version

- Samsung Galaxy S4 - OS:4.4.2
- Samsung Galaxy S4 - OS:5.0.1
- Samsung Galaxy S3 - OS:4.3
- HTC One (M7) - OS:5.0.2
- \*Google Nexus 4 - OS:5.1.1
- \*Google Nexus 6 - OS:5.1.1
- Google Nexus 10 - OS: 5.1.1
- Google Nexus 7 - OS: 5.1.1
- \*Lenovo Tab S8-50F - OS: 4.4.2
- \*Galaxy Tab 4 SM-T230 7" - OS: 4.4.2
- \*Galaxy Tab 4 SM-T530 10.1" - OS: 4.4.2

### BROWSER SUPPORT

#### Browser / OS Version

#### Supported Versions\*

#### Windows (7, 8)

Internet Explorer	10 and 11
Chrome	Latest release
Firefox	Latest release

#### Mac OS (10.6-10.9.1)

Safari	Latest release
Chrome	Latest release
Firefox	Latest release

\* Devices are not officially approved by Panasonic.